CIT 223: Data Communication and Computer Network Lab Assignment #06

Introduction to Routers and Switch Connection

Anup Adhikari anup.adhikari@gandakiuniversity.edu.np Gandaki University

Published Date: July 2, 2024, Deadline Date: July 09, 2024

1 Introduction

In Packet Tracer, you can connect routers and switches to create a network topology. Routers are used to connect different networks or subnets, while switches are used to connect devices within the same network.

- 1. Add a switch and a router to your project. These devices can be found in the device library or palette.
- 2. Connect the switch and router using an Ethernet cable. In the packet tracer software, you can drag and drop cables to create connections between devices.
- 3. Configure the switch and router interfaces. For example, assign IP addresses to the router's LAN interface and switch's VLAN interface.
- 4. Configure VLANs on the switch. Create VLANs and assign ports to respective VLANs.
- 5. Configure routing on the router. Set up routing protocols or static routes to enable communication between VLANs or between the LAN and external networks.
- 6. Connect end devices like computers or servers to the switch ports. Configure IP addresses on the end devices as per the VLAN configurations.
- 7. Test connectivity between devices in the LAN. Verify that the devices can communicate with each other within their respective VLANs and access external networks through the router.

2 Objectives

The objectives of the lab are:

1. to configure switch and router

3 Instructions

3.1 Configuring the Switch

Step 1

- 1. Enter privileged EXEC mode
- 2. Enter global configuration mode
- 3. Set a hostname for the switch
- 4. Configure VLANs.

Command Line

Configuring the VLANs vlan vlan_id name vlan name

Step 2

1. Assign Ports to VLANs.

Command Line

interface interface_id switchport mode access switchport access vlan vlan id

Step 3

Enable Trunking on a port:



Info: Use this command if you want to connect the switch to a router or another switch using a trunk link.

Command Line

interface interface_id
switchport mode trunk

3.2 Configuring the Router

Step 1

Configure the LAN interface

Command Line

interface interface_id
ip address ip_address subnet_mask
no shutdown

Command Line

Configuring the Serial Connection

interface serial <interface_number>
encapsulation hdlc

Replace interface_id with the LAN interface ID (e.g., FastEthernet0/0, GigabitEthernet0/0), ip_address with the IP address for the LAN interface, and subnet_mask with the appropriate subnet mask.

Step 2

Configure the Static Routing

Command Line

ip route network_address subnet_mask next_hop_ip_address

4 Lab Tasks

Question 1

Create a network topology as shown in the Figure 1

Question 2

Create a network topology as shown in the Figure 2




Figure 1: Connecting router and the switch




Figure 2: Connecting routers and the switch

Question 3

Create a network topology as shown in the Figure 3




Figure 3: Connecting 3 routers